

River Course

River Course is a fact sheet series developed to provide information and technologies related to the use of natural channel design in restoring impaired streams.

Finding Bankfull Stage in North Carolina Streams



Dominant, Effective, and Bankfull Discharge

Restoring streams to a stable form through natural channel design requires detailed information about surface water hydrology and the interactions between rainfall and overland flow or runoff. The channel-forming or dominant discharge is the most common method for sizing channel dimension if the stream restoration requires re-shaping the channel. Channel dimension is the cross sectional shape of the channel, including channel width, depth, and cross sectional area. **Dominant discharge** is a theoretical discharge that if constantly maintained in an alluvial stream over a long period of time will produce the same channel geometry that is produced by the long-term hydrograph. **Effective discharge** is defined as the discharge that transports the largest percentage of the sediment load over a period of many years. Effective discharge is

the peak of a curve obtained by multiplying the flood frequency curve and the sediment discharge rating curve (Figure 1). **Bankfull discharge** is the discharge that fills a stable alluvial channel to the elevation of the active floodplain. This discharge is morphologically significant because it identifies the point where the active channel stops and the floodplain begins. In other words, it represents the breakpoint between the processes of channel formation and floodplain formation.

Since bankfull discharge is the only discharge that can be identified in the field using physical indicators, it is the one most commonly used in natural channel design. Most river engineers and




Figure 1. Effective discharge determination from sediment rating and flow duration curves. The peak of curve C marks the discharge that is most effective in transporting sediment. (Wolman and Miller, 1960)

hydrologists work under the assumption that dominant, effective, and bankfull discharges are approximately equal. This assumption has not been proven true in the Southeast; however, the differences will probably not significantly affect a natural channel design.

Field Indicators of the Bankfull Stage

The height of water, or stage, during bankfull flow is the point at which flooding occurs on the floodplain. This may or may not be the top of the streambank. If the stream has downcut due to changes in the watershed or streamside vegetation, the floodplain stage indicator may be a small bench or scour line on the streambank. The top of the bank, which was formerly the floodplain, is called a terrace in this case. A stream with a terrace near the top of the banks is an incised, or entrenched, stream. If the stream is not entrenched, then

Distributed in furtherance of the Acts of Congress of May 8 and June 30, 1914. Employment and program opportunities are offered to all people regardless of race, color, national origin, sex, age, or disability. North Carolina State University, North Carolina A&T State University, U.S. Department of Agriculture, and local governments cooperating.



College of Agriculture & Life Sciences • NC State University
School of Agriculture • NC A&T State University

bankfull is near the top of the bank. On average, bankfull discharge occurs approximately every 1.5 years. In other words, each year there is about a 67 percent chance of having at least one bankfull streamflow event. The bankfull event can occur any number of times per year.

The Rosgen stream classification system uses bankfull stage as the basis for measuring the width/depth ratio and entrenchment ratio, two of the most important delineative criteria. Therefore, it is critical to correctly identify bankfull stage when classifying streams and designing stream restoration measures. The Rosgen stream classification system is

discussed in detail in *Application of the Rosgen Stream Classification System in North Carolina*, AG-590-2.

The most consistent bankfull indicator in North Carolina streams is the uppermost scour line. Other bankfull indicators include the back of a point bar, the upper break in slope of the bank, and occasionally the top of the bank. Often, there is another prominent feature known as the inner berm. The Army Corps of Engineers refers to the inner berm as the mean high water mark. This feature is usually identified as a scour line or small bench halfway between the low flow water surface and the bankfull stage. While this

feature is morphologically significant, it is not the dominant discharge and should thus not be used for sizing a channel. Examples of bankfull indicators are included in Figure 2.

Regional Curves

Bankfull hydraulic geometry relationships, also called regional curves, first developed by Dunne and Leopold (1978), related bankfull channel dimensions to drainage area. Gage station analyses throughout the United States have shown that the bankfull discharge has an average return interval of about 1.5 years or 67 percent annual exceedence probability. The primary

Figure 2. Examples of the inner berm and bankfull indicators.



2a. Mills River Gage, Henderson County, C4 stream type. The break in slope at the lower bench is the inner berm (IB). Bankfull (BKF) is the upper scour line.



2b. Rocky Branch, Wake County, G4/F4 stream type. This stream is actively building a new floodplain. The front of the bench is the inner berm and bankfull is the back of the bench.



Figure 2c. South Fork Mitchell River, Surry County, C4/E4 stream type. Bankfull is rarely the top of a point bar. However, in cases where there is an excessive upstream sediment supply, a point bar will build to bankfull as shown in this photograph. The inner berm is the lower bench.



Figure 2d. Hominy Creek, Wilson County, E5 stream type. Bankfull is the break in slope near the top of the bank. Notice the deposition on the floodplain. The inner berm is the lower bench inside the channel.

purpose for developing regional curves is to aid in identifying bankfull stage and dimension in un-gaged watersheds and to help estimate the bankfull dimension and discharge for natural channel designs. The bankfull cross sectional area vs drainage area regional curve for North Carolina rural piedmont is shown in Figure 3.

Details about the development of regional curves and additional data for the rural piedmont of North Carolina are discussed by Harman et al., (1999). Additional curves for North Carolina physiographic regions will be posted on the web at the following address as they are completed: <http://www.bae.ncsu.edu/bae/programs/extension/wqg/sri>.

Finding and Verifying Bankfull Stage in the Field

The following steps should be taken for identifying and verifying the bankfull stage in the field **on an un-gaged stream**.

- Using a USGS quad sheet or similar map, determine the drainage area in miles squared for the watershed/stream section of interest.
- Calculate the percent of impervious cover for the watershed of interest.
- Using the indicators listed above, walk upstream and downstream for a distance of at least 20 times the bankfull width and flag the bankfull indicators.
- Use a survey rod to measure the difference between the bankfull indicator and the current water surface along the study reach. The variability of this difference should not be more than 6 inches.
- At a riffle or run, pull a tape from the left bankfull indicator to the right bankfull indicator (cross section). Measure the depth to the channel bed/bottom (Y_i), from a level line at bankfull or use a survey

Incremental area between X_2 and X_3

$$= (X_3 - X_2) [(Y_2 + Y_3)/2]$$

$$= (6.7 - 5.1) [(1.2 + 2.0)/2]$$

$$= 2.56 \text{ ft}^2$$




Figure 3. North Carolina rural piedmont curve.

- instrument, at several stations (X_i) along the cross section. Be sure to choose points that correspond to breaks in slope. Spacing between points should not be more than $1/4$ the width of the channel. An example is provided in Figure 4. Calculate the cross sectional area (A_{bkf}) as follows:
- $A_{bkf} = \sum (X_{i+1} - X_i) [(Y_i + Y_{i+1})/2]$
- where, X_i = cross section distances (widths) to successive vertical depths measured from the left bankfull station and Y_i = the vertical depth.
- The bankfull width (W_{bkf}) is measured as $X_{right \text{ bkf}} - X_{left \text{ bkf}}$
- 6. For your watershed area and percent impervious cover, compare the field estimated bankfull cross sectional area to the area on the regional curve for that stream's hydrophysiographic region. If it is




Figure 4. Example cross-section survey. The X_i represent cross-section distances (widths) from the left pin. The Y_i represents the location and reading of a bankfull depth. The dashed line (inset at left) equals the calculated mean depth for a section. The shaded rectangle shows an example of the sectional area. Add incremental areas across the entire cross section to get total cross-sectional area.

close to the regression line (between the upper and lower 95 percent confidence limits, dashed lines on Figure 3) **AND** the feature is consistent for 20 bankfull widths, then this feature is (most likely) the bankfull stage.

If the measured bankfull cross sectional area falls outside of the 95 percent confidence limit, the following steps should be taken.

1. Recheck calculations.
2. If the point is below the lower 95 percent confidence limit, make sure that the feature is not the inner berm. Typically, the inner berm has roughly half the cross sectional area as bankfull. Look for other features above the inner berm, such as an upper scour line or break in slope that are consistent for a longer distance upstream and downstream of the cross section.
3. If the point is low, be sure there is not an upstream impoundment.
4. If the point is above the rural curve but below the urban curve, it may be part of a separate relationship for suburban development.
5. Visit a nearby gage station and check the return interval for BKF. It should be between 1 and 2 years.
6. Finally, know your watershed! Factors such as stream type, impervious cover, topography, channel materials, sediment transport, and bank vegetaion all contribute to the size of a bankfull channel.

Conclusion

Successfully identifying bankfull stage is the crux to any stream restoration design. With practice and experience, bankfull can be identified correctly and consistently in stable and moderately unstable streams. Regional curves should be used as an aid in verifying which morphological feature is or is not bankfull. When possible, gage stations near the project site should be surveyed and compared to the regional curve. If a gage station is surveyed, the bankfull stage should be carried through the gage plate to obtain a bankfull discharge from the stage/discharge relationship. Using the bankfull discharge and Log Pearson Type III flood frequency

distribution, a return interval or exceedence probability can be obtained. The return interval should be between 1 and 2 years.

If regional curves are used for natural channel design, other methods such as Manning's equation or HEC 2/ HEC RAS should be used to estimate the bankfull discharge for comparison. If a sediment/ discharge relationship and flow duration curve is available for the project, then the effective discharge should be used for the design. In all cases, professional judgment is required to make the final design decisions. Therefore, it is imperative that the designer understands the cause and effect relationships governing the morphology of the channel.

References

- Dingman, L.S. 1994. *Physical Hydrology*. Prentice-Hall, Inc. Upper Saddle River, NJ.
- Dunne, T. and L.B. Leopold. 1978. *Water and Environmental Planning*. W.H. Freeman Company. San Francisco, CA.
- Federal Interagency Stream Restoration Working Group. 1999. *Stream Corridor Restoration: Principles, Processes, and Practices*. Federal Interagency Stream Restoration Working Group. Washington, D.C.
- Harman, W.H. et al. 1999. Bankfull Hydraulic Geometry Relationships for North Carolina Streams. *AWRA Wildland Hydrology Proceedings*. AWRA Summer Symposium. Bozeman, MT.
- Rosgen, D.L. 1994. *A Classification of Natural Rivers*. Catena, vol 22: 169-199. Eisevier, B.V. Amsterdam.

Prepared by
William A. Harman
Extension Specialist, Biological and Agricultural Engineering

5,000 copies of this public document were printed at a cost of \$xxx, or \$.xx per copy.